


1. Remove Cover




2. Disconnect Power/loop



3. Place remover tool underneath the chip



4. Rotate the remover tool round to be verical so it prises against the PCB



5. Repeat the steps for the other side of the chip



6. Use the forked tool to remove the chip as shown



7. Package up the removed chip(s) and return to Head Office.